





	NC1	NC2	NC3
Tu0C0000000	H	L	L
Tu0C0000000	L	H	L
Tu0C0000000	L	L	H
Tu0C0000000	L	L	H
Tu0C0000000	L	L	H
Tu0C0000000	L	L	H







BLUE TOOTH

MULTIMEDIA CHIP (CL851S64)


DC/DC Down Converter(1.875V)




PCB HOLE





VDD_IO_HIGH	2.8V
VDD_IO_LOW	1.8V
VDD_WB	2.8V
VDD_RANGE	1.8V
AVDD	2.8V
AVDD_HFA	2.8V
VCC_RK_TX	2.8V
VCC_2V8	2.8V
VDD_GEM_CORE	1.8V
VDD_CORE_B7	1.8V
VDD_WB_2.8	2.8V
VDD_AU	4V




MICROPHONE




MIC_SEL	
H	EARPHONE MIC
L	MAIN MIC



EARPIECE




KEY_LED




FLIP	
H	SLIDE UP
L	SLIDE DOWN


KEY_MAP




VOLUME_KEY




CAMERA_KEY




CAMERA




CAM FLASH




B'D CONNECTOR






CODEC_EN	
H	CODEC ON
L	CODEC OFF



AUDIO_SEL	
H	MAIN - EARPHONE
	CODEC - LOUD SPK
L	CODEC - EARPHONE
	MAIN - LOUD SPK



AMP_EN	
H	AMP ON
L	AMP OFF

