

## Part List

- mechanical -



*Xperia™ ZL*

*C6502, C6503, C6506 & L35h*

**CONTENTS**

1    **Part List ..... 3**

2    **Revision History ..... 9**

## 1 Part List

The following parts are available for order in 'E-star'.

The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.



Designation	Part No.	Part	Location
Adhesive Backcover	1267-3073		
Adhesive Battery	1267-3738		
Adhesive Label	1266-7336		
Adhesive NFC	1271-7128		
Adhesive Vibrator	1270-2598		
Adhesive Vibrator Wire	1267-5758		
Ant NFC	1264-7334		
Attachment Power Key	1266-7093		

Designation	Part No.	Part	Location
<b><u>Back Cover</u></b> Back Cover Assy Black Back Cover Assy Red Back Cover Assy White	1266-7038 1270-2408 1269-2915		
Battery 2300 mAh	1264-3476		
Battery Grounding	1270-9062		
Camera 13 MP	1264-5459		
Camera 2.2 MP	1268-6092		
<b><u>Carrier Antenna</u></b> Carrier Antenna Carrier Antenna RoW	1270-2128 1266-7018		
Carrier Sidekey	1266-7017		
<b><u>Carrier Spbox</u></b> Carrier Spbox Carrier Spbox RoW	1270-2131 1266-7016		
Carrier Ear Piece Holder	1267-6153		
Clip USB	1267-3000		

Designation	Part No.	Part	Location
<b><u>Cover Card</u></b> Cover Card Black Cover Card Red Cover Card White	1266-7027 1270-2413 1269-2914		
<b><u>Earspeaker</u></b> Ear Speaker 12.0 Rectangular	1244-5343		
FPC AVP	1261-9755		
FPC Camera key PBA	1265-3974		
FPC Side Key	1261-9757		
<b><u>Front Assy</u></b> Front Assy Black Front Assy Red Front Assy White	1267-5458 1270-2378 1269-2880		
Gasket Battery FPC Support	1267-6223		
Gasket Proximity	1270-6928		
Gasket Vibrator	1270-2596		
Grommet AVP	1266-7051		

Designation	Part No.	Part	Location
<b><u>Key Camera</u></b> Key Camera Black Key Camera Red Key Camera White	1266-7101 1270-2395 1269-3864		
Key Power	1266-7091		
<b><u>Key Volume</u></b> Key Volume Black Key Volume Red Key Volume White	1266-7098 1270-2394 1269-3866		
Label Mobile Phone	1266-7039		
Mic Protection Tape	1272-4636		
<b><u>Panel Bottom</u></b> Panel Bottom Black Panel Bottom Red Panel Bottom White	1266-7078 1270-2392 1269-3861		
<b><u>Panel Side Left</u></b> Panel Side Left Black Panel Side Left Red Panel Side Left White	1266-7087 1270-2393 1269-3862		
<b><u>Panel Side Right 1</u></b> Panel Side Right 1 Black Panel Side Right 1 Red Panel Side Right 1 White	1266-7065 1270-2388 1269-3858		
<b><u>Panel Side Right 2</u></b> Panel Side Right 2 Black Panel Side Right 2 Red Panel Side Right 2 White	1266-7070 1270-2390 1269-3859		
<b><u>Panel Top</u></b> Panel Top Black Panel Top Red Panel Top White	1266-7073 1270-2391 1269-3860		

Designation	Part No.	Part	Location
<b><u>Screw 1.6</u></b> Screw Other Len:1.6 Diam:1.4	1223-5057		
<b><u>Screw 3.0</u></b> Screw Phillips Len:3.0 Diam:1.4	1232-2921		
<b><u>Screw 3.5</u></b> Screw M1.4x3.5	1204-8506		
Shield Can Chat Camera	1267-6264		
Silicon Camera Key	1266-7102		
Silicon Power Key	1266-7097		
Silicon Volume Key	1266-7099		
<b><u>WI Bottom</u></b> Water Indicator	1239-5490		
<b><u>WI Top</u></b> Water Indicator	1201-4047		

Designation	Part No.	Part	Location
Vibrator	1264-7699		



## 2 Revision History

Rev.	Date	Changes / Comments
1	2013-Feb-27	Initial release